


Utensil Holder

GRILL STATION FLAGSHIP

Every spatula, tong, and griddle scraper in its place



Before you start: Mounts to the *SIDE* of the HUB Mount (sold separately). Install the HUB Mount first — every attachment locks onto it.

What's in the Box

- (1) Utensil Holder unit, fully assembled
- (2) Button Head Cap Bolt 3/8-16 × 3/4" stainless
- (2) Star Knob 3/8-16
- Installation instructions

Tools Required

- 1 × Allen wrench (1/4" hex) — for the button head cap bolts
- Star knobs hand-tighten — no tool needed

Hardware is stainless steel. Do not over-tighten powder-coated surfaces.

Installation

- 1 Position the Utensil Holder against the side of the HUB Mount, lining up its bracket holes with the HUB slots.
- 2 Insert the 2 button head cap bolts through the Utensil Holder bracket into the HUB Mount.
- 3 Thread a star knob onto each bolt from the back of the HUB and hand-tighten until snug.
- 4 Make sure the unit sits level and locked in place before use.

Warranty Lifetime warranty on welded joints and stainless steel hardware. Three (3) year warranty on powder coat finish and all other components.

Thank you for choosing Summit.

Every Summit unit is fabricated from start to finish in the heartland of Illinois — proudly made in the USA. Thanks for trusting us with your build.

— The Summit Cart Mods Team